



ITEM	PART #	MATERIAL	QTY	ITEM	PART #	MATERIAL	QTY
ot	n.a.	outlet, 120VAC, 15A, GFCI	1				
bx	n.a.	j-box, double gang, PVC	1				
awc	n.a.	j-box cover, all weather (hooded)	1				
j1	9109	lag screw 5/16" x 2.5"	2				

DESIGN PARAMETERS:

1. Refer to PRECorp Streetlight Design Guide.
2. 15' minimum outlet mounting height
3. Properly ground and bond all metallic parts.
4. Use all-weather silicon filled "wire-nuts" in j-box.
5. Use crimped and taped connectors where exposed.
6. Refer to drawing U1 for riser installation.

120VAC Outlet Assembly
underground fed

RUS
1/24/2022
REV. 0



U01.RC